





TDS PRODUCT IMAGE SHEET – CATEGORY >		
BEARINGS, BUSHES & ROLLERS		
Images	TDS Part Numbers & Description	OE References & (WHERE FITTED)
	<b>ASY001B</b> BOTTOM BEARING ASSY - Ø22mm ROLLER	<b>215311</b> <i>Peters</i>  33-11130 DP038157 DEP-00014 DEP-0007
	<b>ASY002B</b> BOTTOM BEARING ASSY - Ø25mm ROLLER	<b>218065</b> <i>Peters</i>  108377 DEP-00388 DEP-00410
	<b>ASY003B</b> UNIVERSAL GUIDE SPINDLE LONG Ø30 ROLLER  # ADJUSTMENT 60mm MIN 73mm MAX	<b>H102250</b> <i>Deans</i> <b>H105408</b> <i>Deans</i> <b>216292-KIT</b> <i>Peters</i>  DEP-00016 33-11134 DP038158
	<b>ASY004B</b> UNIVERSAL GUIDE SPINDLE SHORT Ø30 ROLLER  # ADJUSTMENT 48mm MIN 60mm MAX	<b>216264-KIT</b> <i>Peters</i> <b>0123268</b> <i>Deans</i> <b>H102249, 106070</b> <b>033889B-10A</b>  32450040 6690802N12 DEP-00066
	<b>ASY005A</b> BOTTOM BEARING ASSY – Ø32mm ROLLER	<b>ASY005A</b> <i>TDS</i>

	<p><b>ASY006B</b>          INLINE BOTTOM BEARING –          Ø25mm ROLLER</p>	<p><b>75-22155</b> Deans          DED-0100A</p>
	<p><b>ASY007A</b>          INLINE BOTTOM BEARING –          Ø22mm ROLLER</p>	<p><b>215144</b> Peters          117663</p>
	<p><b>ASY008A</b>          INLINE BOTTOM BEARING –          Ø32mm ROLLER</p>	<p><b>D21059</b> Deans</p>
	<p><b>ASY009B</b>          SOLO INLINE BOTTOM          BEARING –          Ø25mm ROLLER</p>	<p><b>ASY009B</b> TDS          6690833N00          16R0241</p>
	<p><b>ASY010A</b>          SOLO INLINE BOTTOM          BEARING –          Ø32mm ROLLER</p>	<p><b>032024+5</b> Deans          227681          16R0016          16R0017</p>
 <p>ASY011A</p>	<p><b>ASY011A</b>          M12x1.75          SPH PIVOT PLATE ASSY</p>	<p><b>022680</b> Overton  <b>03717B-7</b> Overton          42-5093820</p>
	<p><b>ASY013A</b>          TRI BOTTOM BEARING –          Ø25mm ROLLER</p>	<p><b>C25245</b> Deans          66900013          DP038159</p>

	<p><b>ASY014A</b> TRI BOTTOM BEARING – Ø32mm ROLLER</p>	<p><b>C23262</b> Deans <b>C23632</b> Deans <b>C44067</b> Deans</p> <p>DP038165 6690802F01</p>
	<p><b>ASY015A</b> LONG INLINE BOTTOM BEARING – Ø22mm ROLLER</p>	<p><b>215957</b> Peters <b>215958</b> Peters</p> <p>69L0008 69L0009</p>
	<p><b>ASY018A</b> M12x1.75 SPH PIVOT PLATE ASSY</p>	<p><b>024820</b> Overton</p>
	<p><b>ASY019A</b> Ø 10 SPH BEARING PLATE ASSY</p>	<p><b>045470</b> Deans <b>D34018</b> Deans <b>031821</b> Deans</p> <p>66132870 DP038168</p>
	<p><b>ASY020A</b> M12x1.75 SPH PIVOT PLATE ASSY</p>	<p><b>100-0034-KIT</b> Peters</p> <p>DP038194 DEP-00359 DEP-00046</p>
	<p><b>ASY023T</b> SPINDLE ASSY LONG=97xM16 Ø32 ROLLER</p>	<p><b>026426 Assy</b> Deans</p> <p>70-0066-000</p>

	<p><b>ASY024T</b> SPINDLE ASSY SHORT =71xM16 Ø32 ROLLER</p>	<p><b>026425 Assy</b> Deans</p>
	<p><b>ASY029A</b> M14 SPH BOTTOM ASSY 35mm HGT</p>	<p><b>216760-ASY</b> Peters  DEP-00153</p>
	<p><b>ASY030A</b> M14 SPH BOTTOM ASSY 24mm HGT</p>	<p><b>217631-ASY</b> Peters</p>
	<p><b>ASY031</b> Ø22 BEARING HOUSING ASSY</p>	<p><b>205580+90</b> Peters</p>
	<p><b>ASY032T</b> SPINDLE ASSY M12x64 Ø30 ROLLER # SEE SPL015 = SPINDLE SEPARATELY</p>	<p><b>022648=</b> Overton <b>ASY032T</b> TDS</p>
 <p>ASY033</p>	<p><b>ASY033</b> RH SIDE No1 DOOR MOUNTED BOTTOM BEARING ASSY Ø32 ROLLER</p>	<p><b>0101567</b> Deans  6601007N00</p>
 <p>ASY034</p>	<p><b>ASY034</b> LH SIDE No2 DOOR MOUNTED BOTTOM BEARING ASSY Ø32 ROLLER</p>	<p><b>0101568</b> Deans  6601008N00</p>

	<p><b>AS Y035T</b> DOOR GUIDE SPINDLE Ø30x 94mm. M10 FIXING OFF SET</p>	<p><i>Bode</i></p>
	<p><b>AS Y040</b> BOTTOM BEARING BRACKET Ø12 SPH BEARING (BRG046=12x22x7) KKT=Door System</p>	<p><b>H102923</b> <i>Deans</i>  6690803N13</p>
	<p><b>AS Y043</b> LH GUIDE BRKT+SPINDLE ASSY (LONG) - (BRK054+AS Y003)</p>	<p><b>0104967</b> <i>Deans</i></p>
	<p><b>AS Y044</b> RH GUIDE BRKT+SPINDLE ASSY (LONG) (BRK055+AS Y003)</p>	<p><b>0104968</b> <i>Deans</i></p>
	<p><b>AS Y065T</b> SPINDLE ASSY LONG =97xM16 Ø32 ROLLER</p>	<p><b>ISAF</b> (OPTARE VERSA)</p>
	<p><b>BRG001A</b> PLAIN NYLON BEARING Ø22mm Bore Ø38.5mm O/D x 14mm</p>	<p><b>205580</b> <i>Peters</i></p>
	<p><b>BRG002A</b> TOP HAT NYLON FLANGE BEARING Ø22mm Bore</p>	<p><b>200377</b> <i>Peters</i>  DEP-00345 DP038178</p>

	<p><b>BRG003A</b> PLAIN NYLON BEARING Ø25mm bore Ø39mm O/D x 25mm</p>	<p><b>201421</b> <i>Peters</i></p>
	<p><b>BRG004B</b> OILTE BEARING BUSH I/D 3/4"x 7/8"x 1"</p>	<p><b>203327</b> <i>Peters</i></p>
	<p><b>BRG007B</b> M12x1.25 RH FEMALE RODEND</p>	<p><b>BRG007B</b> <i>TDS</i></p>
	<p><b>BRG008B</b> M10x1.5 LH MALE RODEND</p>	<p><b>203280</b> <i>Peters</i> <b>B128</b> <i>Ventura</i></p>
	<p><b>BRG009B</b> M10x1.5 RH MALE SPH RODEND</p>	<p><b>203281</b> <i>Peters</i> <b>B127</b> <i>Ventura</i></p>
	<p><b>BRG010B</b> M12x1.75 RH MALE SPH RODEND</p>	<p><b>203286</b> <i>Peters</i> <b>049651</b> <i>Deans</i></p> <p style="text-align: right;">66903241 DEP-00015</p>
	<p><b>BRG011B</b> M16x1.5 RH FEMALE SPH RODEND</p>	<p><b>BRG011B</b> <i>TDS</i></p>

	<p><b>BRG012B-ASSY</b> 1/2 UNF RH MALE SPH RODEND ASSY</p>	<p><b>E11311</b> <i>Deans</i></p> <p>66902760 DP038154 16R0032</p>
	<p><b>BRG013B-ASSY</b> 7/16 UNF RH MALE SPH RODEND ASSY</p>	<p><b>E13306</b> <i>Deans</i></p> <p>DP038155</p>
	<p><b>BRG014B</b> M12x1.75 LH MALE SPH RODEND</p>	<p><b>BRG014B</b> <i>TDS</i></p>
	<p><b>BRG015B</b> M14x2.0 RH MALE SPH RODEND</p>	<p><b>BRG015B</b> <i>TDS</i></p> <p>6690819N00 16R0289</p>
	<p><b>BRG016B</b> Ø10 X 8.0 DU BUSH</p>	<p><b>203323</b> <i>Peters</i></p>
	<p><b>BRG017B</b> M16x2.0 RH MALE SPH RODEND</p>	<p><b>BRG017B</b> <i>TDS</i></p>
	<p><b>BRG018B</b> M14x2.0 LH MALE SPH RODEND</p>	<p><b>BRG018B</b> <i>TDS</i></p>

	<p><b>BRG019B</b> Ø 10mm SPH BEARING RACE O/D=26x10.5</p>	<p><b>041339</b> <i>Deans</i>  669003081</p>
	<p><b>BRG021B</b> Ø14 SPH BEARING RACE O/D=34x13.5</p>	<p><b>216767</b> <i>Peters</i>  DEP-00157</p>
	<p><b>BRG022B</b> Ø25 FLANGED SPH NY-BEARING</p>	<p><b>0100559</b> <i>Deans</i> <b>BRG022B</b> <i>TDS</i>  6690802G01</p>
	<p><b>BRG023B</b> Ø25 FLANGED SPH BEARING</p>	<p><b>216751</b> <i>Peters</i>  DEP-00203</p>
	<p><b>BRG024B</b> Ø12 FLANGED NY-BEARING</p>	<p><b>034616</b> <i>Deans</i></p>
	<p><b>BRG025B</b> Ø12 x 12 OILITE FLANGED BUSH</p>	<p><b>203352</b> <i>Peters</i>  33-11137</p>
	<p><b>BRG026B</b> Ø12 x 8 OILITE FLANGED BUSH</p>	<p><b>BRG026B</b> <i>TDS</i>  22450046</p>



 <p>BRG027B</p>	<p><b>BRG027B</b>          Ø6 x 10 FLAP          NY-FLANGED BUSH</p>	<p><b>BRG027B</b> TDS</p>
	<p><b>BRG029B</b>          Ø16 x 20 x 18od NY-SLEEVE          CLUTCH BEARING</p>	<p><b>BRG029B</b> TDS</p>
	<p><b>BRG030B</b>          Ø12 x 20 x 14od NY-SLEEVE          HINGE BEARING</p>	<p><b>BRG030B</b> TDS</p>
	<p><b>BRG031B</b>          Ø1/2x1/2 DU BUSH</p>	<p><b>200362</b> Peters</p>
 <p>BRG035</p>	<p><b>BRG035</b>          TOP NYLON          BEARING</p>	<p><b>034641</b> Deans          66902825          DP038188          69F0505</p>
	<p><b>BRG036</b>          Ø16 FLANGED NY-BEARING          ID=16x6 (CYLINDER REAR)</p>	<p><b>BRG036</b> TDS          (OPTARE OLYMPUS DD)</p>
	<p><b>BRG037</b>          Ø14 SPH BEARING KGLM-14          OD=28x13.5          (Fits on ASY025)</p>	<p><b>0100605</b> Deans          6690823D177</p>








 <p><b>BRG040D</b></p>	<p><b>BRG040D</b> RODEND - PDS CYLINDER</p>	<p><b>200362</b> <i>Peters</i></p> <p>DEP-00036</p>
 <p><b>BRG045</b></p>	<p><b>BRG045</b> STEELBEARING SLEEVE Ø19-16x40 DEANS CYLINDER BRACKET</p>	<p><b>BRG045</b> <i>TDS</i></p>
	<p><b>BRG046</b> Ø12 SPH BEARING EGLM-12 OD=22x7 (FITS INTO ASY040 &amp; ASY027)</p>	<p><b>0100606</b> <i>Deans</i></p> <p>6690804N13 16R0228</p>
	<p><b>BRG048</b> NYLON SHELFPLATE BEARING</p>	<p><b>220137</b> <i>Overton</i></p> <p>053571B-5</p>
	<p><b>BRG050F</b> RH BEARING PLATE PDS REPLACES OE EXTRUSION PART </p>	<p><b>200273</b> <i>Peters</i></p> <p>DP038164 DEP-00344</p>
	<p><b>BRG051F</b> LH BEARING PLATE PDS REPLACES OE EXTRUSION PART </p>	<p><b>200274</b> <i>Peters</i></p> <p>DP038162 DP038171 DEP-00421</p>
	<p><b>BRG052</b> USED TO CONVERT TDS SPH BRG 25mm SHELFPLATE TO STD BRG TOP HAT TYPE 22mm BRG002 FIXING CNTRE=76 x 8.5slots</p>	<p><b>BRG052</b> <i>TDS</i> (ELECTRIC FOLDERS)</p>






	<p><b>BRG055</b> M14x1.5 MALE xSTUD M10x1.0 FINE THREAD</p>	<p><b>80071</b> <i>Deans</i> POST-1995</p>
	<p><b>BRG056</b> M18 MALE x STUD=M10x1.5 MALE FINE THREAD B10B</p>	<p><b>80073</b> <i>Deans</i> PRE-1995  DED-00113</p>
	<p><b>BRG057B</b> M6x1.0 RH SPH FEMALE RODEND</p>	<p><b>D26185</b> <i>Deans</i> <i>Rodend Only</i> <b>0103479</b> <i>Deans</i> (IG)</p>
	<p><b>BRG058</b> Ø6 PLUG SLIDER LOWER SHAFT GUIDE RADIAL BEARING OD=19x6</p>	<p><b>0102265</b> <i>Deans</i> (E200 DEANS PS)</p>
	<p><b>BRG061B</b> M8 x 1.25 RH MALE SPH RODEND</p>	<p><b>BRG061B</b> <i>TDS</i></p>
	<p><b>BRG062B</b> M8 x 1.25 LH MALE SPH RODEND</p>	<p><b>BRG062B</b> <i>TDS</i></p>
	<p><b>BRG063B</b> M12 X 1.75 RH FEMALE SPH RODEND</p>	<p><b>BRG063B</b> <i>TDS</i></p>

	<p><b>BRG064</b> Ø16mm DIA SPH BEARING RACE</p>	<p><b>0100287</b> <i>Deans</i></p>
	<p><b>BRG065</b> CLOSED SLIDE CARRIAGE BEARING</p>	<p><b>048492</b> <i>Deans</i> (E200 DEANS PS)</p>
	<p><b>BRG066</b> OPEN SLIDE CARRIAGE BEARING</p>	<p><b>H110116-010675</b> <i>Deans</i> (E200 DEANS PS)</p>
	<p><b>BRG068B</b> Ø10 x 6 x 12od NY-SLEEVE</p>	<p><b>0101454</b> <i>Deans</i> <i>Plug slider lower arm</i></p>
	<p><b>BRG070-01-KIT</b> DOUBLE LINK TRANSVERSE LINK ASSY</p>	<p><b>H102623</b> <i>Deans</i> (E200 DEANS PS)</p>
	<p><b>BRG071</b> M14 X 1.5 FEMALE TO Ø16 SPH ROD END DEANS USED REDUCER TO Ø16 TO Ø12</p>	<p><b>0108269</b> <i>Deans</i> NOW GO TO BRG080 M14 X 1.5 FEMALE TO Ø12 SPH ROD END</p>
	<p><b>BRG072</b> Ø20 ROLLER BEARING OD=42x12</p>	<p><b>048484</b> <i>Deans</i> (E200 DEANS PS ROLLER CARRIAGE)</p>

	<p><b>BRG073-KIT-01</b>  M16x2 to M12x1.75  MALE SPH ROD END  WITH FIXINGS  (UNIVERSAL PART -  PLAG DOOR PIVOT ARMS)</p>	<p><b>BRG073-KIT-01</b> TDS</p> <p># SEE ALSO  BRK070-28, RUB045, SAB040</p>
	<p><b>BRG073-KIT-02</b>  M16x2 to M12x1.75  MALE SPH ROD END  WITH FIXINGS  (UNIVERSAL PART -  PLAG DOOR PIVOT ARMS)</p>	<p><b>BRG073-KIT-02</b> TDS</p>
	<p><b>BRG074</b>  7/16"UNF LH MALE  SPH RODEND</p>	<p><b>E13307</b> Deans</p>
	<p><b>BRG075B</b>  M12 X 1.75 LH FEMALE  SPH RODEND</p>	<p><b>BRG075B</b> TDS</p>
	<p><b>BRG076</b>  ALTERNATIVE LINKBALL  JOINT FOR TBS12</p>	<p><b>BRG076</b> TDS</p>
	<p><b>BRG077B</b>  M10x1.5 RH FEMALE SPH  ROD END</p>	<p><b>BRG077</b> TDS</p>
	<p><b>BRG078B</b>  M10 X 1.5 LH FEMALE  SPH ROD END</p>	<p><b>BRG078B</b> TDS</p>

	<p><b>BRG080</b> M14x1.5 RH FEMALE THREAD TO Ø12 SPH ROD END (Ø16 SPH ROD END WITH REDUCER TO Ø12 SPH)</p>	<p><b>0108268 Deans</b></p>
	<p><b>BRG081B</b> Ø16 x 20 x 22od NY-SLEEVE (CENTRE CRANK ARMS)</p>	<p><b>BRG081B TDS</b></p>
	<p><b>BRG082</b> M14x1.5 RH MALE TRACK RODEND M10x1.5 STUD</p>	<p><b>B400007 BCE</b></p>
	<p><b>BRG083</b> M14x1.5 LH MALE TRACK RODEND M10x1.5 STUD</p>	<p><b>B400024 BCE</b></p>
	<p><b>BRG085</b> M10 IGUBALL FEMALE RODEND</p>	<p><b>218058 Peters</b></p>
	<p><b>BRG086</b> BCE PIVOT ARM BALL JOINT ASSY</p>	<p><b>B600216 BCE</b></p>
	<p><b>BRG090</b> PIVOT BRACKET &amp; BEARING POST</p>	<p><b>B705073 BCE</b></p>

 <p>Ø10 39 Ø33.5</p>	<p><b>BRG091</b>          Ø10xØ33.5x39          BEARING BUSH          For spring=SPG024          For bearing pin=BRG092</p>	<p><b>372138A0</b> Masats</p>
 <p>M16x1.5 Ø10 Ø6 78 97</p>	<p><b>BRG092</b>          Ø10xØ33.5x39          BEARING PIN          For spring=SPG024          For bearing bush=BRG091</p>	<p><b>870137C0</b> Masats</p>
	<p><b>BRG096</b>          M16x2 BODY-M12x1.75          STUD BALL JOINT</p>	<p><b>10050.04.0</b> ISAF          (OPTARE VERSA – ISAF DOOR)          29455026</p>
	<p><b>BRG100</b>          FEMALE BEARING BUSH</p>	<p><b>473124B0</b> Masats</p>
	<p><b>DS-H101747</b>          PS BOTTOM BEARING          ASSY LH</p>	<p><b>H101747</b> Deans          (ADL E400 OLDER)</p>
	<p><b>DS-H101750</b>          PS BOTTOM BEARING          ASSY RH</p>	<p><b>H101750</b> Deans          (ADL E400 OLDER)</p>
 <p>KIT015</p>	<p><b>KIT015</b>          IG 3 HOLE DOOR GUIDE          BRACKET SPINDLE KIT</p>	<p><b>200285/288</b> Peters</p>








	<p><b>KIT016</b> IG 4 HOLE DOOR GUIDE BRACKET SPINDLE KIT</p>	<p><b>200298</b> <i>Peters</i></p>
	<p><b>L500-05-ASSY-01</b> IG Ø14 UPPER BEARING BRACKET ASSY</p>	<p><b>L500-05-ASSY-01</b> <i>TDS</i> (ALL OPTARE – TDS DOOR)  DP0383826</p>
	<p><b>L500-09-ASSY-01</b> IG Ø14 LOWER BEARING BRACKET ASSY</p>	<p><b>L500-09-ASSY-01</b> <i>TDS</i> (ALL OPTARE – TDS DOOR)  6690832N00</p>
	<p><b>RLR001A</b> Ø22mm O/DIA X 17mm Ø 12.75mm I/DIA NYLON ROLLER FOR BOTTOM BEARING</p>	<p><b>205606</b> <i>Peters</i>  66902499 DEM-00068</p>
	<p><b>RLR002A</b> Ø25mm O/DIA X 17mm Ø 12.75mm I/DIA NYLON ROLLER FOR BOTTOM BEARING</p>	<p><b>200435/200547</b> <i>Peters</i> <b>E22156</b> <i>Deans</i>  66902177</p>
	<p><b>RLR003A</b> Ø32mm O/DIA X 17mm Ø 12.75mm I/DIA NYLON ROLLER FOR DEANS BOTTOM BEARING</p>	<p><b>026437</b> <i>Deans</i>  66902213</p>
	<p><b>RLR004A</b> Ø30mm O/DIA X 16mm Ø 12.75mm I/DIA (NYLON ROLLER FOR EARLY PETERS GUIDE SPINDLES)</p>	<p><b>205751</b> <i>Peters</i> <b>215593</b> <i>Peters</i>  DP038161 DEM-00068 DAE550</p>



	<p><b>RLR005A</b>          Ø32mm O/DIA X 17mm          Ø 9.65mm I/DIA          (NYLON ROLLER FOR DEANS GUIDE SPINDLES)</p>	<p><b>E32682</b> Deans          126847</p>
	<p><b>ROD002-290-01</b>          M12x360CTRS SPH LINK          ROD ASSY KIT          # OTHER SIZE/RODEND OPTIONS AVAILABLE</p>	<p><b>ROD002-290-01</b> TDS</p>
	<p><b>A441</b></p>	<p><b>A441</b> Ventura          6690812L010</p>
	<p><b>A841</b>          Ø10 BEARING ROLLER          6000 LLU. OD=26x8</p>	<p><b>A841</b> Ventura          DED-00178          42-5145-133</p>
	<p><b>A925</b>          GUIDE ROLLER LR 202 2RSR</p>	<p><b>A925</b> Ventura          DED-00187          669082D237</p>
	<p><b>A937</b>          Ø10 DOOR SPACER          ID=10.0x15. OD=15.0          F= Ø20x4</p>	<p><b>A937</b> Ventura          DED-00177          DP039835</p>
	<p><b>B253</b>          Ø16 NYLON BEARING BUSH          ID=16x22. OD=22          F= Ø30x2.5          (DOORSHAFT TOP ARM)</p>	<p><b>B253</b> Ventura          DEV-00006          42-5145-715          6690807N00</p>








	<p><b>B688</b> PS PIVOT BOLT 16xM10  (BOTTOM SUPPORT ASSY)</p>	<p><b>B688</b> <i>Ventura</i>  DED-00205 6690818D31 42-5145-688</p>
	<p><b>B689</b> PS SHAFT BEARING BUSH ID=16.5. OD=21-23 LG=24. F= Ø 30x3.0  (ALL PS/RS DOORSHAFTS)</p>	<p><b>B689</b> <i>Ventura</i>  DED-00204 6690800N33</p>
	<p><b>B708</b> Ø12 BEARING BUSH MFM-1216-10 ID=12.5x10. OD=16.25 F=22x2  (RS DOOR MECHANISM)</p>	<p><b>B708</b> <i>Ventura</i></p>
	<p><b>B711</b> M8x1.25 RH MALE SPH RODEND (BRONZE BUSH)  (PS CONNECTOR RODS)</p>	<p><b>B711</b> <i>Ventura</i> <b>BRG061</b> TDS  DED-00199 42-5145-169</p>
	<p><b>B712</b> M8x1.25 LH MALE SPH RODEND (BRONZE BUSH)  (PS CONNECTOR RODS)</p>	<p><b>B712</b> <i>Ventura</i> <b>BRG062</b> TDS  DED-00200 42-5145-168</p>
	<p><b>C395</b> IG RUBBER BUSH 50mm NBR 65  (CYLINDER REAR BRKT)</p>	<p><b>C395</b> <i>Ventura</i>  6690803F75</p>

	<p><b>C519</b> CONNECTING ROD M8x50</p>	<p><b>C519</b> <i>Ventura</i> (PLAXTON PRESIDENT DD PS) 42-5145-167</p>
	<p><b>D105</b> GUIDE ROLLER Ø12 ROLLER BEARING OD=30x8</p>	<p><b>D105</b> <i>Ventura</i> 42-5145-D105</p>
	<p><b>D107</b> Ø12 BEARING BUSH ID=12x7. OD=14 F=19.75x1.0</p>	<p><b>D107</b> <i>Ventura</i> DED-00318 6690804D31</p>
	<p><b>D112</b> Ø 25 BEARING BLOCK FLCTEY (IG3 DOORSHAFT ASSYS) # FIXINGS = H425 BOLT, A808 NUT &amp; D870 LOCK DISC</p>	<p><b>D112</b> <i>Ventura</i> DEV-00073 6690801N39</p>
	<p><b>D552</b> Ø24 ROLLER ASSY ID=14x12 (DOORSHAFT ROLLER ASSY LOWER ARM)</p>	<p><b>D552</b> <i>Ventura</i> 42-5145-552A</p>
	<p><b>D760</b> SPACER 16/10 L23.5</p>	<p><b>D760</b> <i>Ventura</i> (BLUEBIRD &amp; MELLOR ORION) DED-00262 6690816D31 42-5145-760</p>

	<p><b>D803</b> LOCATING BUSH  (PS BOTTOM SUPPORT ASSY)</p>	<p><b>D803</b> <i>Ventura</i>  DEV-00162 DP733705</p>
	<p><b>E456</b> Ø25 GUIDE ROLLER OD=25x6.75. ID=18</p>	<p><b>E456</b> <i>Ventura</i>  DEV-00148</p>
	<p><b>E464</b> Ø16 HYLON BEARING ID=16x9. OD=18 F=23.75x1</p>	<p><b>E464</b> <i>Ventura</i>  DEV-00157</p>
	<p><b>E515</b> PS CONNECTING ROD M8x50 ASSY</p>	<p><b>E515</b> <i>Ventura</i> WRIGHTBUS ECLIPSE SD PS + STREETCAR PS, ADL E200 SD PS, PLAXTON PRESIDENT DD PS, OPTARE SD TEMPO PS, POLISH SCANIA OMNICITY DD PS, MCV DD EVOSETI PS2  42-5145-515 DED-00335</p>
	<p><b>E529</b> PS Ø10 GUIDE ROLLER LR 200 2RSR PS OD=30x9</p>	<p><b>E529</b> <i>Ventura</i> WRIGHTBUS NBFL DD  DED-00336 6690836D177</p>
	<p><b>F169</b> PS CONNECTING ROD M8x75 ASSY</p>	<p><b>F169</b> <i>Ventura</i> WRIGHTBUS GEMINI DD</p>
	<p><b>F170</b> PS CONNECTING ROD M8x120 ASSY</p>	<p><b>F170</b> <i>Ventura</i> WRIGHTBUS GEMINI DD</p>

	<p><b>F230</b> PS CONNECTING ROD M8x90 ASSY</p>	<p><b>F230</b> <i>Ventura</i> WRIGHTBUS GEMINI DD</p>
	<p><b>F640</b> FLANGED BEARING BUSH Ø8x10 OD=10  (IG3 FLAPS)</p>	<p><b>F640</b> <i>Ventura</i>  DEV-00355 669082221L013</p>
	<p><b>F681</b> IG Ø14 PLAIN SPH BEARING DIN648 GE14 ID=14. OD=28x13.35 (TOP DOORSHAFT ARMS)</p>	<p><b>F681</b> <i>Ventura</i>  DEV-00007 6690813F75</p>
 <p>4215</p>	<p><b>G215</b> BEARING BUSH 15</p>	<p><b>G215</b> <i>Ventura</i></p>
	<p><b>G951</b> PIVOT BOLT 21DIA M10</p>	<p><b>G951</b> <i>Ventura</i>  DEV-00034 DED-00471 6690824N33</p>
	<p><b>G968</b> BUSH DIA 16-10 L=14</p>	<p><b>G968</b> <i>Ventura</i> WRIGHTBUS IG4  DEV-00160 6690822D237</p>
	<p><b>H072</b> IG3 SHAFT BEARING BUSH IB=21. OD=29.25-30 LG=30. F= Ø 38x5 (ALL IG3 DOORSHAFTS)</p>	<p><b>H072</b> <i>Ventura</i>  DEV-00008 6690804N00</p>





	<p><b>H074</b>  <b>Ø12.4 NYLON BEARING BUSH</b>          Bore =12.4 OD=16.25          LG=10, F= Ø22 x 2.0 thk          (IG3 DOORSHAFT LOWER BRACKET)</p>	<p><b>H074</b> <i>Ventura</i></p> <p>DEV-00546 6690805N00</p>
	<p><b>H080</b>  <b>CONNECTING ROD END M8</b></p>	<p><b>H080</b> <i>Ventura</i>          WRIGHTBUS PS2</p> <p>DEV-00405</p>
	<p><b>H096</b>  <b>PIVOT BOLT M12</b></p>	<p><b>H096</b> <i>Ventura</i></p>
	<p><b>H119</b>  <b>SPACER BUSH 30</b></p>	<p><b>H119</b> <i>Ventura</i></p> <p>DED-00511 6690801F75 6690800N127</p>
	<p><b>H706</b>  <b>BUSH 10-6,5 L=12</b></p>	<p><b>H706</b> <i>Ventura</i></p> <p>DED-00506 6690809N00</p>
	<p><b>H750</b>  <b>Ø 26mm PSP ROLLER ASSY</b>          OD=26x10. ID=21x8          (D755+D758)</p> <p># ASSOCIATED PARTS:          D760 SPACER, B706 BOLT</p>	<p><b>H750</b> <i>Ventura</i></p> <p>DED-00257 42-5145-755A 66903320</p>

	<p><b>H780</b> GUIDE RING – SPIRAL CABLE</p>	<p><b>H780</b> <i>Ventura</i></p>
	<p><b>H818</b> LINEAR BEARING - RS</p>	<p><b>H818</b> <i>Ventura</i> BLUEBIRD ORION RS</p>
	<p><b>I120</b> RS Connection Rod M8 (1210L)</p>	<p><b>I120</b> <i>Ventura</i></p>
	<p><b>I162</b> IG4 SHAFT BEARING BUSH IB=21. OD=32-33 LG=30. F=Ø38x5</p>	<p><b>I162</b> <i>Ventura</i> ADL IG3 DOORSHAFTS ALL IG4 DOORSHAFTS (2010&gt;) NBFL IG4 PLAT, NBFL IG4 PS</p> <p>DEV-00185 6690817F75</p>
	<p><b>I220</b> PIVOT POINT BOLT SHORT (IG3)</p> <p># BEARING BUSH = H074</p>	<p><b>I220</b> <i>Ventura</i></p> <p>DEV-00544 6690813N00</p>
	<p><b>I221</b> RING</p>	<p><b>I221</b> <i>Ventura</i></p> <p>DED-00517 6690806N00</p>
	<p><b>I261</b> BEARING BUSH bore Ø16x16.88xØ18 Flange Ø24 x 1.0 thk</p>	<p><b>I261</b> <i>Ventura</i> WRIGHTBUS PS</p>

	<p><b>I274</b> BUSH DIA o/d=12, i/d=9, L=9.5</p>	<p><b>I274</b> <i>Ventura</i> WRIGHTBUS PS2</p> <p>DEV-00418</p>
	<p><b>I653</b> bore Ø8.0x5.5 x Ø10 Flange Ø15.0 x 0.87 thick</p>	<p><b>I653</b> <i>Ventura</i></p>
	<p><b>I714</b> GUIDING SHAFT ASSY 106 Lg -96ctr x Ø28 with <b>CABLE ENTRY</b></p> <p># ROLLER ASSY = J301</p>	<p><b>I714</b> <i>Ventura</i> EAST LANCS SD/DD IG3, MCV SD IG4, ADL E200 SD IG4 + E400 DD IG4 (SENS EDGE CABLE ENTRY)</p> <p>6690809D177</p>
	<p><b>I830</b> PS CONNECTOR ROD M8 x 58 ASSY</p>	<p><b>I830</b> <i>Ventura</i> ADL E200 SD PS + E400 DD PS, OPTARE SD VERSA PS, POLISH SCANIA OMNICITY DD PS</p> <p>6690800N223</p>
	<p><b>I893</b> GUIDING SHAFT ASSY 99 Lg-89ctr x Ø28 with <b>CABLE ENTRY</b></p> <p># ROLLER ASSY = J301</p>	<p><b>I893</b> <i>Ventura</i> ADL E400 DD IG3, POLISH SCANIA OMNICITY DD IG3</p>
	<p><b>I989</b> GUIDING SHAFT ASSY 87 Lg-78ctr x Ø28 with <b>CABLE ENTRY</b></p> <p># ROLLER ASSY = J301</p>	<p><b>I989</b> <i>Ventura</i> WRIGHTBUS DD DUBLIN + GEMINI DD IG4 + NBFL DD IG4/IG4 PLAT, ADL E300 SD IG3 + DD E400+500 IG3 DUBLIN, TEMSA SD IG4, MCV DD EVOSETI (SENS EDGE CABLE ENTRY)</p> <p>66903314 DEV-00085 DEV-00047</p>



	<p><b>J015</b> CONNECTING ROD M8 X 735 RS ASSY</p>	<p><b>J015</b> <i>Ventura</i>  6690827D237</p>
	<p><b>J301</b> Ø28mm IG GUIDE ROLLER ASSY (E503+504)  (ALL VS GUIDING SHAFT ASSYS)</p>	<p><b>J301</b> <i>Ventura</i>  DEV-00013 DEV-00364 DEV-00365 6690803N33 6690810D177</p>
	<p><b>J405</b> CATCH BLOCK BOTTOM SUPPORT PS</p>	<p><b>J405</b> <i>Ventura</i> ADL E200 (MAY11-DEC13)  6690803D252</p>
	<p><b>J796</b> PS CABLE ROLLER ASSY (A841+B471)</p>	<p><b>J796</b> <i>Ventura</i>  DEV-00396 66908070 42-5145-132</p>
	<p><b>K437</b> PS SPINDLE ROLLER ASSY (D134+D136)</p>	<p><b>K437</b> <i>Ventura</i></p>
	<p><b>K581</b> CONNECTING ROD END M8</p>	<p><b>K581</b> <i>Ventura</i> WRIGHTBUS PS2</p>

	<p><b>K651</b> LINEAR BEARING 30mm KS30-B-PP</p>	<p><b>K651</b> <i>Ventura</i> WRIGHTBUS PS2</p> <p>DEV-00392 6690802S005</p>
	<p><b>K992</b> Ø30 PS ROLLER ASSY OD=30x15. ID=10 (A841+B442)</p>	<p><b>K992</b> <i>Ventura</i></p>
	<p><b>L067</b> (J302) GUIDE ROLLER ASSY 85Lg-75ctrs x Ø28</p> <p># ROLLER ASSY = J301</p>	<p><b>L067</b> <i>Ventura</i></p> <p>WRIGHTBUS ECLIPSE SD IG3 + GEMINI DD IG4, E300 SD IG3, ADL E400 DD IG3, EAST LANCS SD &amp; DD IG3, MCV SD 112/124RLE IG4 (NO CABLE ENTRANCE)</p> <p>DED-00422 6690800N26</p>
	<p><b>L535</b> BUSH DIA12-8 L=86</p>	<p><b>L535</b> <i>Ventura</i> WRIGHTBUS IG4</p> <p>DEV-00305 6690814S01</p>
	<p><b>L538</b> PLATE PLAIN BEARING</p>	<p><b>L538</b> <i>Ventura</i></p> <p>6690831D237</p>
	<p><b>L559</b> CONNECTING ROD M8x700 RS ASSY</p>	<p><b>L559</b> <i>Ventura</i> WRIGHTBUS NBFL DD IG4/IG4 PLAT</p> <p>DEV-00099</p>

	<p><b>L560</b> CONNECTING ROD RS 700</p>	<p><b>L560</b> <i>Ventura</i> WRIGHTBUS NBFL DD IG4 PLAT</p>
	<p><b>L744</b> IG4 FLAP BEARING POINT  (ALL IG4 DOOR FLAPS)</p>	<p><b>L744</b> <i>Ventura</i>  DEV-00136 6690823D177</p>
	<p><b>L745</b> Ø8 BEARING BUSH ID=8.25x12. OD=9.12 F=13x0.42  (ALL IG4 DOOR FLAPS)</p>	<p><b>L745</b> <i>Ventura</i>  DEV-00333 6690818D177</p>
	<p><b>L782</b> Ø12.35 NYLON BEARING BUSH MFM ID=12.35x8 OD=18.0 F= Ø23.75x2.9</p>	<p><b>L782</b> <i>Ventura</i>  DEV-00179 6690816F75</p>
	<p><b>L805</b> BEARING LOCK FLCTEY</p>	<p><b>L805</b> <i>Ventura</i>  DEV-00177 6690812F75</p>
	<p><b>L886</b> IG4 PIVOT POINT BOLT SHORT  # BEARING BUSH = H074</p>	<p><b>L886</b> <i>Ventura</i>  DEP-00459</p>

	<p><b>M117</b> CONNECTING ROD M8x955 RS ASSY</p>	<p><b>M117</b> <i>Ventura</i> BLUEBIRD SD RS</p>
	<p><b>M195</b> BUSH DIA=20-16 L=25 POM</p>	<p><b>M195</b> <i>Ventura</i> WRIGHTBUS IG4</p> <p>DEV-00175 6690824D177</p>
	<p><b>M236</b> SPACER POM L=20</p>	<p><b>M236</b> <i>Ventura</i></p> <p>DEV-00175 6690802F75</p>
	<p><b>O101</b> BEARING BUSH POTENTIOMETER</p>	<p><b>O101</b> <i>Ventura</i></p> <p>6690833E001</p>
	<p><b>O102</b> POTENTIOMETER BUSH IG4</p>	<p><b>O102</b> <i>Ventura</i></p> <p>6690812L013</p>
	<p><b>O731</b> GUIDE BLOCK</p>	<p><b>O731</b> <i>Ventura</i> NBFL IG PLATFORM</p>

	<p><b>P261</b> CATCH BLOCK BOTTOM SUPPORT</p>	<p><b>P261</b> <i>Ventura</i> WRIGHTBUS PS2</p> <p>DEV-00102 6616803L120</p>
	<p><b>S878</b> CONNECTING ROD M8</p>	<p><b>S878</b> <i>Ventura</i> WRIGHTBUS PS2</p> <p>DEV-00403</p>
	<p><b>T500</b> CONNECTING ROD M8x41 ASSY</p>	<p><b>T500</b> <i>Ventura</i> WRIGHTBUS PS2</p> <p>DEV-00397 6690808L010</p>
	<p><b>T896</b> CONNECTING ROD M8x50 ASSY</p>	<p><b>T896</b> <i>Ventura</i> WRIGHTBUS NBFL DD PS</p> <p>DEV-00766</p>
	<p><b>VA0317</b> GUIDING SHAFT ASS. 98mm LG x M10</p> <p># ROLLER ASSY = J301</p>	<p><b>VA0317</b> <i>Ventura</i> ADL E200/E400 EV</p> <p>6690815E001</p>
	<p><b>VA0633</b> ROLLER GUIDING SHAFT</p>	<p><b>VA0633</b> <i>Ventura</i></p> <p>6690846L002</p>
	<p><b>VA0634</b> BEARING BUSH GSM</p>	<p><b>VA0634</b> <i>Ventura</i></p> <p>6690801S005</p>

	<p><b>VA0946</b> PSE SHAFT COUPLER 10-12</p>	<p><b>VA0946</b> <i>Ventura</i> ADL E200 EV  6690821E001</p>
	<p><b>VA0948</b> PSE SPINDLE NUT</p>	<p><b>VA0948</b> <i>Ventura</i> ADL E200/E400 EV PSE</p>
	<p><b>VA1107</b> PSE SPRING SPACER BUSH</p>	<p><b>VA1107</b> <i>Ventura</i></p>
	<p><b>VA1108</b> PSE SPRING BUSH</p>	<p><b>VA1108</b> <i>Ventura</i></p>
	<p><b>VA1617</b> BUSH 12-05 L=16</p>	<p><b>VA1617</b> <i>Ventura</i>  6690849L002</p>
	<p><b>VA2778</b> BEARING BUSGH GFM</p>	<p><b>VA2778</b> <i>Ventura</i>  6690834L013 6690804S005</p>